

STAR BENCH

**YOUR BENCH IS SUPPLIED ASSEMBLED WITH:
FOUR GROUND FIXING BOLTS**

TOOLS REQUIRED:
15mm Spanner
8mm Masonry Bit

1. Use an 8mm masonry drill bit to drill a hole in the ground through the holes in the star ends to a depth of 130mm.

2. Screw the bolts into the holes through the star ends using a 15mm spanner.

3. Tighten with spanner to secure your Bench to the ground.

Your Bench is now secure and ready for use!!