


Our optional ground fixing bolts are recommended where permanent outdoor fixing is required. Will prevent theft, overturning and unauthorised re-positioning of your bins.

GROUND FIXING BOLTS


MIDI, MICRO, SLIMLINE CLASSIC AND PENCIL

- 1** 1. By placing the bolts through the two holes mark the ground




TOOLS REQUIRED:
15mm Spanner
8mm Masonry Bit

- 2** 2. Drill two 8mm holes in the marked positions to a depth of 125mm.




3



- 3** 3. Screw the bolts into the holes through the base using a 15mm spanner.

4



- 4** 4. Tighten with spanner to secure your bin to the ground